

HENRY® 444

FRP Panel Adhesive


The Professional's Formula For Success when installing fiberglass reinforced plastic panels.

APPLICATIONS:

- USE ONLY FOR:
Fiberglass reinforced plastic panels.
- BONDS TO: Concrete, plywood, gypsum drywall and plaster on all grade levels as recommended by the panel manufacturer.

TECHNICAL DATA:

- Base: Water-based/rubber-resin
 - Color: Off-white
 - Taggant Color: Fire-orange
 - Open Time: None
 - Working Time: 30 minutes
- NOTE: Working times vary based on job conditions, substrates, temperature, and humidity.
- Size: Gallon, 4 Gallon
 - Shipping Unit: Gallon: 4 gallons/ctn
4 Gallon: 1 pail
 - Weight Per Gallon: 11.5 lbs
 - Quantity Per Pallet: Gallon: 30 ctns
4 Gallon: 48 pails
 - Shelf Life: One year if not opened
 - Freeze-Thaw Stable: Keep from freezing
 - Trowels/Coverage:



V-NOTCH 1/4D x 1/4W x 3/4A
50-60 sq ft/gal

DIRECTIONS:

Refer to panel manufacturer's specific recommendations. Condition the area to be installed, adhesive and flooring at 65°F (18°C) or above for 48 hours before, during and 48 hours after installation. Floor must be sound, smooth, dry, clean and free of excessive moisture or alkali. Remove dirt, wax, loose paint and all other foreign matter that would interfere with a good bond such as curing agents and sealers. This adhesive should not be used in situations where odors may be transmitted to foodstuffs. When installing FRP to ceilings, follow the manufacturer's recommendations and use permanent mechanical fasteners in conjunction with adhesive. When installing FRP over below-grade concrete or block walls where moisture can penetrate from the back, attach furring strips with mechanical fasteners and adhesive. Then adhere panels using solid backing if needed.

- Stir any liquid on the surface into the adhesive.
- Cut and pre-fit panels. Lay panels flat and let them acclimate to room temperature for 12-24 hours before installing.
- Full spread adhesive over entire surface using recommended trowel. Do not leave bare spots. Press down firmly on the spreader so that adhesive does not remain between ridges.
- Place panel against subsurface immediately. Press firmly over entire surface working from center to edges so that entire back of panel is in full contact with backing.
- For channel moldings and for permanent fasteners, follow the panel manufacturer's recommendations. Do not fit panels too tightly into moldings. A minimum 1/16" expansion space is needed.

WARRANTY: We warrant that HENRY 444 will not break down or lose its cohesive strength due to a manufacturing or formulation defect for 10 years from the date of installation, if used for its stated purpose and applied in accordance to the instructions, subject to certain exclusions and limitations set forth in the warranty.

WARNINGS: Carefully read and follow all cautions and warnings on the product label. Refer to the Material Safety Data Sheet for additional product information.

CLEANUP: Wet Adhesive: Clean, white cloth dampened with soapy water.
Dried Adhesive: Clean, white cloth dampened with mineral spirits; carefully following warnings on the container.

UPC INFORMATION: Gallon: 0-81833-44440-7
4 Gallon: 0-81833-44495-7

The W. W. Henry Company
400 Ardex Park Drive
Aliquippa, PA 15001
Technical Support: 1-800-232-4832
Internet: wwhenry.com