

# EKABLUE GRIT SANDING STEPS

# SOLID SURFACE FINISHING

FOR SEAMS / DEEP SCRATCHES, START WITH 80 GRIT AS 1ST STEP

FOR HIGH GLOSS FINISH - USE FINISH II COMPOUND AND A VARIABLE

SPEED BUFFER WITH A WHITE WOOL PAD.

#### MEDIUM GLOSS FINISH

- 120 GRIT
- 220 GRIT
- 320 GRIT
- 400 GRIT
- 600 GRIT
- WHITE SCOTCH BRITE

## SATIN FINISH

- 120 GRIT
- 220 GRIT
- 320 GRIT
- 400 GRIT
- GREY SCOTCH BRITE

## **MATTE FINISH**

- 120 GRIT
- 220 GRIT
- 320 GRIT
- 400 GRIT
- MAROON SCOTCH BRITE

STOCK EKABLUE PATTERN

FESTOOL PATTERN



6 x 17 Holes (©Festool) TIP: Darker Colors may require more of a gloss finish to reduce hazy

appearance.

