



# Hybond®

## PRODUCT DATA SHEET

CHOICE BRANDS ADHESIVES, 666 REDNA TERRACE #500, CINCINNATI, OH 45215 513-772-1234

**Product Number:** HY-70M

**Description:** Neoprene OTC Contact Adhesive, Brush Grade

### Typical Physical Properties:

<b>Class:</b>	Extremely Flammable	<b>Flash Point:</b>	-4 deg F
<b>Viscosity:</b>	2250 cps	<b>Coverage:</b>	152 sq ft/gal
<b>Dry Time:</b>	8 - 12 minutes	<b>Clean Up:</b>	Choice Brands 689 Cleaner
<b>Solids:</b>	24.0% +/- 1%	<b>Coverage rate:</b>	2.5 dry g/sq ft minimum
<b>Open Time:</b>	60 minutes	<b>VOC:</b>	249 g/l (EPA method 24)
<b>Color:</b>	Natural	<b>Shelf Life:</b>	1 year from date of manufacture
<b>Solvents:</b>	Organic Solvents	<b>Packaging:</b>	5 gl, 54 gl and tote containers

**Qualifies for LEED®-NC & CI EQ Credit 4.4: *laminating adhesives shall contain no urea formaldehyde resins***

### Properties:

- OTC Compliant
- Premium flammable brush grade contact cement.
- Excellent adhesion to a variety of substrates including, but not limited to laminates, particle board, plywood, hardwood, leather, rubber and metal
- Excellent room temperature contactability
- Excellent green strength and high heat resistance
- Postformable
- Spreads easily and provides uniform coverage
- Fast drying formula
- One hour open time

### Application:

1. For best results, agitate adhesive before use.
2. Substrates should be clean and free of moisture, dirt, oil and other contaminants.
3. For best results, adhesive and substrates should be allowed to acclimate to room temperature (approximately 60°F or above) before adhesive application.
4. The adhesive can be applied with an animal hair or solvent-resistant brush, a short-nap roller, or a roll coater.
5. The adhesive should be applied at approximately 2.5 dry grams/square foot. The adhesive should cover 100% of the substrate surface. The substrate surface should exhibit a uniform glossy sheen when the adhesive is completely dry. Dull areas indicate insufficient coverage. Adhesive should be reapplied to these areas.
6. When bonding porous substrates, it is advisable to apply two coats of adhesive. The first coat will act as a sealer and prevent excessive absorption of adhesive into the substrate. After the

NOTICE TO PURCHASER: The information, data and suggestions for use of the materials given here are based on our best experience and knowledge, but we do not guarantee the results to be obtained in customer's processes. The products discussed are sold without any warranty regarding merchantability or fitness for a particular purpose or any other warranty express or implied. Before using, user shall determine the suitability of the product for his intended use, and user assumes all risk and liability whatsoever in connection therewith. Neither seller nor manufacturer shall be liable for any injury, loss or damage, direct or consequential, arising out of the use of or the inability to use the product. Sellers and manufacturers only obligation shall be to replace such quantity of the product proved to be defective. Since the manufacturer of the described in this data sheet has no means of controlling the final use of the product by the consumer or user, it is the responsibility of the immediate purchaser and any intermediate sellers to inform the user of the purposes for which the product may be fit and suitable, and of the properties of the product, including the precautionary measures which much be taken in order to insure the safety of the user and of other third persons and property.



# Hybond<sup>®</sup>

## PRODUCT DATA SHEET

CHOICE BRANDS ADHESIVES, 666 REDNA TERRACE #500, CINCINNATI, OH 45215 513-772-1234

first coat has dried, apply a second coat. Allow the second adhesive coating to dry completely before assembly.

7. Allowing the contact adhesive to dry completely before assembly is essential to obtaining a secure, permanent bond. To check for adhesive dryness, press the back of your fingers onto the adhesive surface. If adhesive transfers to fingers, additional dry time is necessary. If there is no adhesive transfer, the substrates are ready for bonding.

8. If areas exist with excessive adhesive deposition, twist the fingers while pressing them onto the adhesive layer. This will break any skin that may have formed as the adhesive dries from the top surface down. If a skin has formed, allow additional dry time to ensure complete evaporation of the solvent before bonding.

9. Dry times can be improved through the use of air movement, drying ovens, lamps, etc.

10. Substrates may be indexed together and bonded once the adhesive is dry. Bonds must be made within the open time of the adhesive.

11. Uniform pressure on the bonded laminates is necessary to create strong, lasting bonds. 40 pounds per linear inch is recommended to ensure complete fusion between the two layers of adhesive. A pinch roller is the ideal method for applying uniform pressure. When used properly, a J-roller can also provide sufficient pressure for bonding.

12. All contact adhesive bonds are immediately able to be routed, trimmed, cut, filed and machined

### **Application Precautions:**

Do not use in applications with copper components.

Do not use on polystyrene foams or plasticized vinyls

Do not mix with other adhesives. Thinning the adhesive is not recommended.

### **Storage Conditions:**

Rotate stock, use oldest first.

Keep covered to prevent solvent loss and contamination.

Do not freeze. Do not store at high temperatures.

Do not store in direct sunlight.

**Please Refer To The Material Safety Data Sheet For Further Information.**